



DATA SHEET



LuminOx O₂ Sensors

Luminescence-based Optical Flow-Through Series

FEATURES

- Luminescence–based optical technology, NOT electrochemical
- Contains no hazardous materials; RoHS & REACH compliant
- Connects directly to a microcontroller without any additional circuitry
- Factory calibrated
- High accuracy, fast response
- Maintenance free^a





BENEFITS

- Compact, flow-through housing with sealed base
- Low power, long life due to non-depleting sensing principle

a)

b)

Low cost

XTECHNICAL SPECIFICATIONS

Supply voltage (Vs) Supply current (Is) 4.5—5.5V_{DC} <7.5mA (streaming or

Output Type Temperature Operating: Storage: Humidity Barometric pressure range

Maximum flow rate

NOTES

<7.5mA (streaming one sample per second), <20mA Peak 3.3V TTL level USART

+10°C to +45° -30°C to +60°C 0—99% Rh (non-condensing) 500—1200mbar 1.0 litre/min

COUTPUT VALUES^b

Oxygen range Oxygen pressure range Response time Accuracy ppO2 Temperature Pressure O2 Resolution ppO2 Temperature Pressure O2 Lifetime

Other sensor options available on request, email: technical@sstsensing.com

> Need help? Ask the expert Tel: + 44 (0)1236 459 020 and ask for "Technical"



0-25% O₂

< 2% FS

+5mbar

0.1mbar

0.1°C

1mbar

0.01%

> 2 years

Indication only

0-300mbar ppO2

T90 < 10s (typical)

Determined by ppO₂ & pressure accuracy

The sensor housing can be cleaned using a damp cloth. Do NOT immerse the sensor in any cleaning media.

At ambient conditions. All performance measurements are at STP unless otherwise stated. Following extreme temperature fluctuations, re-calibration may be required.





OUTLINE DRAWING

All dimensions shown in mm. Tolerances = ± 0.5 mm.



NOTE: 4.5mm OD push-fit tubing connectors.

ELECTRICAL INTERFACE

	Pin	Designation
	1	Vs (+5V)
	2	GND (0V)
	3	3.3V USART Sensor Transmit
	4	3.3V USART Sensor Receive

CONNECTION: Four gold-plated pins (0.64mm²) on a 2.54mm grid for PCB mounting via sockets or hand soldering using no-clean flux.

NOTE: Do NOT put the sensor through a PCB washing process.

NOTE: Always apply power to sensor pins 1 and 2 before attempting to communicate on pins 3 and 4.



The sensor should be treated as an electronic component and handled using the correct ESD handling precautions.

SENSOR CONSTRUCTION



Specify the part number below when ordering:

L O X - 0 2 - F

Do not exceed maximum ratings and ensure sensor(s) are operated in accordance with their requirements.

Carefully follow all wiring instructions. Incorrect wiring can cause permanent damage to the device. Do NOT use chemical cleaning agents.

Failure to comply with these instructions may result in product damage.

These products must not be used in safety applications where product failure could cause injury or risk to life

As customer applications are outside of SST Sensing Ltd.'s control, the information provided is given without legal responsibility. Customers should test under their own conditions to ensure that the equipment is suitable for their intended application.

For technical assistance or advice, please email: technical@sstsensing.com

General Note: SST Sensing Ltd. reserves the right to make changes to product specifications without notice or liability. All information is subject to SST Sensing Ltd.'s own data and considered accurate at time of going to print.



DS-0145 REV 3

© 2022 SST SENSING LTD.